



IVAO EGYPT

Egypt Airports TORA data (For flight simulation use only)

HECA

RWY 05C			RWY 05R			RWY 05L			RWY 23C			RWY 23R			RWY 23L		
Holding point	TORA (M)	T.O SHIFT (M)	Holding point	TORA (M)	T.O SHIFT (M)	Holding point	TORA (M)	T.O SHIFT (M)	Holding point	TORA (M)	T.O SHIFT (M)	Holding point	TORA (M)	T.O SHIFT (M)	Holding point	TORA (M)	T.O SHIFT (M)
T1	3736	263	R1	3732	268	A1	3119	182	T6	3715	284	J	2990	311	F1	3712	288
R	3430	569				A2	2813	488	L	3516	483						

HEBA

RWY 14R			RWY 14L			RWY 32R			RWY 32L		
Holding point	TORA (M)	T.O SHIFT (M)	Holding point	TORA (M)	T.O SHIFT (M)	Holding point	TORA (M)	T.O SHIFT (M)	Holding point	TORA (M)	T.O SHIFT (M)
H	3162	238									
G	2581	819									

HEGN

RWY 16L			RWY 16R			RWY 34L			RWY 34R		
Holding point	TORA (M)	T.O SHIFT (M)	Holding point	TORA (M)	T.O SHIFT (M)	Holding point	TORA (M)	T.O SHIFT (M)	Holding point	TORA (M)	T.O SHIFT (M)
J	3700	300	V9	3711	289	V2	3743	257	C	3744	256
H	3381	619	V8	3441	559	V3	3492	508	D	3161	839

HEMA

RWY 33			RWY 15		
Holding point	TORA (M)	T.O SHIFT (M)	Holding point	TORA (M)	T.O SHIFT (M)
B	2576	667			
C	2000	1243			



IVAO EGYPT

Egypt Airports TORA data (For flight simulation use only)

HESH

RWY 04L			RWY 04R			RWY 22L			RWY 22R		
Holding point	TORA (M)	T.O SHIFT (M)	Holding point	TORA (M)	T.O SHIFT (M)	Holding point	TORA (M)	T.O SHIFT (M)	Holding point	TORA (M)	T.O SHIFT (M)
L	2636	445	L	2636	445	J	2471	610	F	2452	629
B	2391	690									